

# EPD-470-5-0.5

TECHNICAL DATA

# Selective Photodiode, 5 mm package

EPD-470-5-0.5 is a GaP based photodiode, mounted into on a lead frame with a clear epoxy lens, without standoff leads. This device is featuring a narrow bandwidth and high spectral sensitivity of 400 – 500 nm.

### **Specifications**

- Spectral Responsivity (Peak):
- Package: Type: **Resin Material:**

470 nm 5mm molding Lead frame Epoxy resin



GaP

(Unit: mm)

# Parameters ( $T_A=25^{\circ}C$ )

ltem	Symbol	Value	Unit
Active Area	A	0.17	mm²
Temperature Coefficient of ID	$T_{C}(I_{D})$	5	1/K
Operating Temperature	T <sub>opr</sub>	-40 +85	°C
Storage Temperature	T <sub>stg</sub>	-40 +100	°C
Soldering Temperature *1	T <sub>sol</sub>	240	°C

\*1 must be completed within 3 seconds at 240°C

# **Electro-Optical Characteristics**

ltem	Symbol	Condition	Min.	Тур.	Max.	Unit
Reverse Voltage *1	V <sub>R</sub>	I <sub>R</sub> =10μΑ	-	10	-	V
Dark Current	I <sub>D</sub>	V <sub>R</sub> =5V	-	5	30	pА
Central Sensitivity Wavelength	λ <sub>C</sub>	V <sub>R</sub> =0V	460	470	480	nm
Responsivity at $\lambda_{C}$	S <sub>λ</sub>	V <sub>R</sub> =0V	-	0.3	-	A/W
Sensitivity Range at 1% * <sup>1</sup>	$\lambda_{min}$ , $\lambda_{max}$	V <sub>R</sub> =0V	385	-	565	nm
Spectral Bandwidth at 50%	$\Delta \lambda_{0.5}$	V <sub>R</sub> =0V	-	100	-	nm
Shunt Resistance	R <sub>SH</sub>	V <sub>R</sub> =10mV	70	100	-	GΩ
Noise Equivalent Power	NEP	λ=470nm	-	4.4x10 <sup>-15</sup>	-	$W/\sqrt{Hz} \cdot W^{-1}$
Specific Detectivity	D*	λ=470nm	-	9.3x10 <sup>12</sup>	-	$\operatorname{cm} \cdot \sqrt{Hz} \cdot \operatorname{W}^{-1}$
Junction Capacitance	CJ	V <sub>R</sub> =0V	-	120	-	рF
Switching Time ( $R_L$ =50 $\Omega$ )	t <sub>r</sub> , t <sub>f</sub>	V <sub>R</sub> =5V	-	200	-	ns
Photo Current at Illuminant A	I <sub>Ph</sub>	V <sub>R</sub> =0V E <sub>V</sub> =1000lx	-	0.2	-	μA

\*<sup>1</sup> information only

*Note:* The above specifications are for reference purpose only and subjected to change without prior notice.



# **Typical Performance Curves**





## Precaution for Use

#### 1. Lead Forming

- Lead forming should be done before soldering.
- When forming leads, the leads should be bent at a point at least 3 mm from the base of the lead. DO NOT use the base of the lead frame as a fulcrum during lead forming!
- DO NOT apply any bending stress to the base of the lead. The stress to the base may damage the PD's characteristics or it may break the PDs.
- When mounted the PDs onto the printed circuit board, the holes on the circuit board should be exactly aligned with the leads of PDs. If the PDs are mounted with stress at the leads, it causes deterioration of the lead and it will degrade the PDs.

#### 2. Soldering Conditions

- Solder the PDs no closer than 3 mm from the base of the lead.
- DO NOT apply any stress to the lead particularly when heat.
- After soldering the PDs, the lead should be protected from mechanical shock or vibration until the PDs return to room temperature.
- The PDs must not be reposition after soldering.
- When it is necessary to clamp the PDs to prevent soldering failure, it is important to minimize the mechanical stress on the PDs.
- Cut the PD leads at room temperature. Cutting the leads at high temperature may cause the failure of the PDs.

#### 3. Static Electricity

- The PDs are very sensitive to Static Electricity and surge voltage. So it is recommended that a wrist band and/or an anti-electrostatic glove be used when handling the PDs.
- All devices, equipment and machinery must be grounded properly. It is recommended that precautions should be taken against surge voltage to the equipment that mounts the PDs.

#### **Soldering Conditions**



